

Step-by-Step Instructions

(PRINT this set of instructions to follow every time you refill your cartridge)

CANON BJI-201BK, BJI-201CMY
APPLEM1949-50-51-52 G/A



Items Needed: gloves, hand-drill, small plugs, dye-based black ink, cyan, magenta & yellow ink, cardboard station #2, aluminum tape, paper towels, review hints & tips and check list

Syringe: Attach needle tip (located inside station # 4) to the syringe tightly. Unscrew lid on ink bottle. Puncture silver seal with needle tip making a small hole in the center of seal. Using the correct color pull the correct amount of ink into the syringe. Rinse syringe and needle tip after every use and before using syringe with another color. Rinse syringe and needle tip with water until the water runs clear.

- 1.) Place a piece of strong tape over the exit port on side of cartridge This is done to prevent cartridge from leaking during refill process.
- 2.) Sit cartridge on some folded paper towels in the upright position (label facing up). Peel back the label on the ink reservoir side only. After peeling back the label, 2 small holes are revealed. You can refill in either of these 2 holes. Pick which of the two holes you want to drill thru. Each hole will have a clear plastic ball sealing it. Drill thru only one hole. This will be your fill-hole.
- 3.) Drill thru the clear plastic ball knocking it into the reservoir. (See photo)
- 4.) Hold the cartridge up at a slight 35-45 degree angle tilting toward the reservoir side when filling. Using the appropriate ink bottle, place the tip of the syringe in the fill-hole and slowly insert 8 ml of black or 6 ml of color. In between inserting ink into the cartridge, gently rock the cartridge back and forth from reservoir side to the sponge side. Make sure you have protected the surface under the cartridge with paper towels or old newspapers. This cartridge may leak slightly from exit port when refilling. If leakage is excessive, you are filling the cartridge too quickly.
- 5.) Plug the cartridge immediately after refilling. If plug is not secure in the fill-hole, the cartridge will leak. Make sure plug is completely wedged in fill-hole so no air can escape.
- 6.) Sit the cartridge upright on paper towels for 10 minutes. Do not remove the tape on bottom of exit port. After 10 minutes, remove the tape from the exit port. A tiny amount of ink will escape from exit port after removing the tape. Sit cartridge upright on paper towels for an additional 10 minutes. Make sure the exit port is not directly touching the paper towel. Do not put cartridge in printer if it is leaking or forming a droplet.

7.) After ink in cartridge has stabilized and is not leaking, reinstall cartridge back in the printer, run cleaning cycles (1-3) and print test. Or Print 3 pages using:

http://www.refills4you.com/support/black_print_test.html Black ink test

http://www.refills4you.com/support/color_print_test.html Color ink Test

Warning: The plugs in this kit will NOT fit into some non-OEM brand cartridges. If plugs do not fit, please use aluminum tape in place of plugs. Randomly check these cartridges after refilling to make sure that the tape remains secure. Otherwise, cartridge can leak. You can also seal the fill hole with a glue gun or candle wax.

AccuBrite, Inc. is not affiliated with the listed printer manufacturers or their subsidiaries. The use by AccuBrite, Inc. does not imply endorsement by or association with the brand name owners. The listed manufacturers, printers and cartridges are used only for the purpose of showing the compatibility of this AccuBrite, Inc. product. All other trademarks, brand names and logos referenced in or on this product are the property of their respective owners. This material is protected by the copyright laws of the United States and other countries. It is illegal to reproduce these instructions. It may not be reproduced, distributed, or altered in any fashion by any entity (either internal or external to AccuBrite), except in accordance with applicable agreements or contracts of licensing, without the express written consent of AccuBrite, Inc.

Copyright © AccuBrite, Inc. 2003-2008. All rights reserved